



# **EXHIBIT A**

## One Shot Process

Daniel Walgarth,  
Bühler Bindler




## One shot process



Movement of pistons and lifting table allows to form product in one shot  
Product properties of shell and filling mass are key for one shot


## Example of dosing profile

### Typical ONE SHOT- curves



## Range of Viscosities applied for Numerical Simulation


Different type of flow functions used for shell and for center filling



Numerical Simulations should reveal differences by testing extremes  
- high viscous shell or filling – low viscous filling or shell

## Modelling of One Shot Process


Simulating influence of different product viscosity



## Effects seen in Numerical Simulation


Comparison of case 1 and 2 - Start of dosing

**Case 1**  
Shell high viscous  
Filling low viscous / Ratio < 1




Shell is okay  
and not  
displaced by  
centre filling

**Case 2**  
Shell low viscous  
Filling high viscous / Ratio > 1




Already in the  
beginning shell  
is displaced by  
the centre  
filling

**Case 1**  
Shell high viscous  
Filling low viscous / Ratio < 1




**Case 2**  
Shell low viscous  
Filling high viscous / Ratio > 1




## Effects seen in Numerical Simulation

Comparison of case 1 and 2 — End of dosing after 1200ms

**Case 1:** Shell high viscous  
Filling low viscous / Ratio < 1



**Case 2:** Shell low viscous  
Filling high viscous / Ratio > 1



Red = shell, Blue = filling, all other colours show different degrees of mixture of both


© Bühler | Bühler Binsler GmbH | C. Ziegler / D. Walgarth | 29.09.2004 | # 21




## Effects seen in Numerical Simulation

End of filling, pull back of product after 1700ms

**Case 1:** Shell high viscous  
Filling low viscous / Ratio < 1



**Case 2:** Shell low viscous  
Filling high viscous / Ratio > 1





© Bühler | Bühler Binsler GmbH | C. Ziegler / D. Walgarth | 29.09.2004 | # 22



## Effects seen in practice (Case 1)

Shell viscous  
Filling low viscous



Shell mass

Filling mass

© Bühler | Bühler Binder GmbH | C. Ziegler / D. Waigarth | 29.09.2004 | # 23

BOHLER

## Effects seen in practice (Case 2)

Shell low viscous  
Filling high viscous



Shell mass



Filling mass

© Bühler | Bühler Binder GmbH | C. Ziegler / D. Waigarth | 29.09.2004 | # 24

BOHLER

## Effects seen in practice

Shell and filling have nearly the same viscosity



Filling mass

Shell mass



© Bühler / Bühler Bredler GmbH | C. Ziegler / D. Walgarth | 29.09.2004 | # 25

BOHLER


## Range of Shear Rates and Viscosities Beginning of dosing

### Case 1

Shell high viscous / Filling low viscous - Ratio < 1



Case 2  
Shell low viscous  
Filling high viscous  
Ratio > 1




© Bühler / Bühler Bredler GmbH | C. Ziegler / D. Walgarth | 29.09.2004 | # 26

BOHLER




## Range of shear rates during dosing process

**Case 1**  
Shell high viscous  
Filling low viscous / Ratio < 1



**Case 2**  
Shell low viscous  
Filling high viscous / Ratio > 1



**Most important for process is flow behavior  
in the low shear rate domain, i.e. < 50 1/s**

## Conclusion of these Results & Future aspects

- Viscosity of products is key for One shot process
- Based on numerical simulation and coupling with physical data (viscosity curves) one shot process can be modeled
- Modelling allows to predict if the process will deliver a „good“ or “bad” product
- Modelling will allow to simplify adjustments of the One shot process
- Modelling will allow to optimize the One shot process according to the needs