


EXHIBIT A

One Shot Process

Daniel Walgarth,
Bühler Bindler




One shot process



Movement of pistons and lifting table allows to form product in one shot
Product properties of shell and filling mass are key for one shot


Example of dosing profile

Typical ONE SHOT- curves



Range of Viscosities applied for Numerical Simulation

Different type of flow functions used for shell and for center filling




Numerical Simulations should reveal differences by testing extremes
- high viscous shell or filling – low viscous filling or shell

© Buhler / Bühler-Bender GmbH | C. Ziegler / D. Walspert | 28.09.2008 | 4/17



Modelling of One Shot Process

Simulating influence of different product viscosity



© Buhler / Bühler-Bender GmbH | C. Ziegler / D. Walspert | 28.09.2008 | 4/18




Effects seen in Numerical Simulation

Comparison of case 1 and 2 - Start of dosing

Case 1


Shell high viscous
Filling low viscous / Ratio < 1



Shell is okay
and not
displaced by
centre filling

Case 2

Shell low viscous
Filling high viscous / Ratio > 1



Already in the
beginning shell
is displaced by
the centre
filling


Case 1

Shell high viscous
Filling low viscous / Ratio < 1



Case 2


Shell low viscous
Filling high viscous / Ratio > 1




Effects seen in Numerical Simulation

Comparison of case 1 and 2 — End of dosing after 1200ms

Case 1: Shell high viscous
Filling low viscous / Ratio < 1



Case 2: Shell low viscous
Filling high viscous / Ratio > 1



Red = shell, Blue = filling, all other colours show different degrees of mixture of both


© Bühler / Bühler Fluidex GmbH | C. Ziegler / D. Witzmann | 23.05.2004 | # 21




Effects seen in Numerical Simulation

End of filling, pull back of product after 1700ms

Case 1: Shell high viscous
Filling low viscous / Ratio < 1




Case 2: Shell low viscous
Filling high viscous / Ratio > 1




© Bühler / Bühler Fluidex GmbH | C. Ziegler / D. Witzmann | 23.05.2004 | # 22



Effects seen in practice (Case 1)



Shell viscous
Filling low viscous




Shell mass

Filling mass

© Bühler | Bühler-Bondur GmbH | C. Ziegler | D. Wappler | 20.09.2004 | # 23

BOHLER

Effects seen in practice (Case 2)



Shell low viscous
Filling high viscous



Shell mass

Filling mass

© Bühler | Bühler-Bondur GmbH | C. Ziegler | D. Wappler | 20.09.2004 | # 24

BOHLER

Effects seen in practice

Shell and filling have nearly the same viscosity




© Böhler | Böhler Steiner GmbH | C. Ziegler / D. Walgerth | 23.03.2004 | # 25

BOHLER

Range of Shear Rates and Viscosities Beginning of dosing

Case 1

Shell high viscous / Filling low viscous - Ratio < 1



© Böhler | Böhler Steiner GmbH | C. Ziegler / D. Walgerth | 23.03.2004 | # 26


BOHLER

Range of shear rates during dosing process

Case 1

Shell high viscous


Filling low viscous / Ratio < 1



Case 2

Shell low viscous

Filling high viscous / Ratio > 1



Most important for process is flow behavior
in the low shear rate domain, i.e. < 50 1/s

Conclusion of these Results & Future aspects

- Viscosity of products is key for One shot process
- Based on numerical simulation and coupling with physical data (viscosity curves) one shot process can be modeled
- Modelling allows to predict if the process will deliver a „good“ or „bad“ product
- Modelling will allow to simplify adjustments of the One shot process
- Modelling will allow to optimize the One shot process according to the needs